

## ASFX Mobile Basket Sensor Instructions




### STEP 1:

Start by removing the sensor box and plug in the ethernet cable to the port on the box.



### STEP 2:

Plug the other side into the ethernet port on the side of the machine.



### STEP 3:

Place the sensor reflector four spaces away from the end of the hopper side using zip ties provided. Repeat the process with the sensor eye and place it across from the opposite side of the reflector using zip ties provided. (Reference picture for placement on basket)







### STEP 4:

Plug in the sensor wire into the high port on the sensor box. Gather the remaining wires into a single group and zip tie them to the basket.



### STEP 5:

Turn the machine on. If the machine isn't in the stop/start mode, this can be done by pressing the  and  arrow simultaneously. Use the  to switch to the stop/start mode and hit the  button. (Reference picture above). Machine is now in sensor mode.